

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

## RRIR2

1

Last edited: 1/09/2010

## **Fuel Tank Part List and Installation Instructions**

TANK P/N: RRIR2

RANGE ROVER (1992-1995) & DISCOVERY (1992-early 2000) - EFI PETROL / DIESEL REPLACEMENT TANK

ltem	Description	Quantity	Part number	Р	С
1	TANK – REPLACEMENT	1	RRIR2		
2	HOSE – FUEL AND EMISSION - 8mm	0.6m			
3	HOSE CLAMP – STAINLESS - 8-16mm	2			
4	HOSE CLAMP – STAINLESS - 20-32mm	2			
5	HOSE CLAMP – STAINLESS - 50-70mm	2			
6	DRAIN PLUG – MAGNETIC – M14 (fitted to tank)	1	DP-M14		
7	SET SCREW – HEX – M10 x 30mm – PLATED 8.8	4			
8	NUT – NYLOC PLATED – M10	4			
9	WASHER – FLAT PLATED – M10	4			
10	WASHER – PANEL PLATED – M10	4			
11	TANK BRACKET - STEEL STABILISER BAR SPACER BLOCK	2	TB-RRIR2		
12	STEEL TUBE EXTENSION – 19mm (FAST FILL)	280mm			
13	STEEL TUBE EXTENSION – 51mm (FILLER PIPE)	280mm			
14	DISC MAGNET (fitted in swirl pot)	1			
15	WARRANTY CARD & INFORMATION SHEET	1			
16	BROWN DAVIS AUTOMOTIVE STICKER	1			

Packed by (**P**): \_\_\_\_\_ Checked by (**C**): \_\_\_\_\_

Date Packed: \_\_\_\_ / \_\_\_ / \_\_\_\_



Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

## RRIR2

2

All Brown Davis Automotive fuel tank kits are manufactured to Australian Standards and the Australian Design Rules where applicable and carry a full **<u>3 Year Warranty</u>**. Construction in 2.0 mm cold rolled, aluminium coated steel ensures maximum strength and durability and minimum corrosion susceptibility. More than 30 years of testing within the field has shown that this gauge of steel is sufficiently impact resistant that an additional tank guard is not necessary (most standard tank guards are thinner than 1.5 mm).

All tanks are M.I.G. (Metal Inert Gas) welded to ensure the strongest possible seams and are baffled to prevent fuel surge. They are then pressure tested using two different techniques to eliminate the possibility of leaks. Drain plugs are fitted horizontally to prevent them being damaged if the tank is scraped over rocks and are magnetic to collect any metallic dirt that may enter your fuel system.

In all cases, Brown Davis Automotive fuel tanks are designed with general off road use in mind and are designed not to compromise ground clearance, entry, exit or ramp over angles.

Please remember it is the driver's responsibility to operate their vehicle in a sensible manner in 4WD conditions, Brown Davis Automotive cannot be held responsible for the abuse of your vehicle and subsequent possible fuel tank damage.

**<u>REPLACEMENT TANKS</u>** This tank is a replacement for the standard tank and fits in the same location. The standard filler is retained as is the fuel gauge sender unit which still works in the same manner except it takes longer to reach empty. Rearrangement of the exhaust system **IS NOT** necessary with this fitment.

## ANY QUESTIONS OR INFORAMTION REQUIRED IN RELATION THE BELOW INSTRUCTIONS PLEASE DO NOT HESTITE TO CONTACT BROWN DAVIS HEAD OFFICE OR ONE OF OUR DISTRIBUTORS.

PLEASE ENSURE ALL CONNECTIONS AND MOUNTINGS ARE CHECKED A SECOND TIME AFTER FINISHING YOUR INSTALLATION TO CONFIRM THERE ARE NO LEAKS AND THAT ALL BOLTS ARE TIGHT. ALWAYS ROAD TEST THE VEHICLE AND MAKE SURE THERE IS COMPLETE SUSPENSION TRAVEL CLEARANCE.

# BROWN DAVIS CAN TAKE NO RESPONSIBILITY FOR AFTER MARKET SUSPENSION SYSTEMS INTERFERING WITH THE TANK, IF FITTED.



Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

## RRIR2

3

## **FITTING**

- 1 Install all brass fittings and magnetic drain plug into the replacement long range fuel tank using teflon tape or the like on all threads (**Refer Diagram 1**). Although your Brown Davis Automotive long range tank has been cleaned and sealed at the factory, it is essential that a final rinse and inspection is carried out to ensure that the new fuel tank is impeccably clean before fitting to your vehicle. Use 4 to 5 litres of petrol, diesel or methylated spirits for this rinsing process which should be drained and discarded afterwards to confirm absolute cleanliness. Wiping out the inside of the injection pump swirlpot with a clean rag down through the pump entry boss in the top of the tank and removing the disc magnet and cleaning it before replacing it in exactly the same position it was in the swirl pot to confirm absolute cleanliness is not a bad idea, nor is a second rinse.
- 2 Disconnect the filler hose and the fast fill breather hose from the standard tank (at the tank end).
- 3 Lift up the carpet in the back, and remove the inspection plate to allow access to the fuel gauge sender/pump hose and wiring connections. Unplug these wires and then unscrew the fuel pick up hose, return hose from the sender/pump unit.
- 4 Unscrew and remove the sender/pump unit from the original tank with the hoses still connected.
- 5 Drain the fuel from the vehicle's original tank using a pump or syphon hose as there is no drain plug on most models.
- 6 Unbolt the rear stabiliser bar mountings to the chassis each side and allow the bar to swing down forward towards the rear axel to give clearance to remove the standard tank. Unbolt and lower to the ground the standard fuel tank.
- 7 Refit the sender/pump unit into the new Brown Davis long range tank using the original plastic screw ring. Outlet pipes should be positioned to point towards the steel screw fittings as per the original tank fitment.
- 8 Remove the vent check valve fitting from the old tank, refit this valve into the expansion chamber fitting in the new tank. **(Refer Diagram 1)** Extend original 6mm plastic vent hose from this fitting across top of tank (using the 8mm fuel and emission hose supplied), ready to reconnect to the standard purge line on chassis.

Lift the long range tank into position. Secure the tank up into position reusing the original bolts. Remove standard filler (51mm) hose, cut the hose in half, extend using the steel filler (51mm) extension supplied (on some models this will need to be done also with the 19mm fast fill breather).

PH: +61 (3) 9762 8722 FAX: +61 (3) 9762 9829 47 Holloway Drive, Bayswater, Victoria, Australia 3153



Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

## RRIR2

4

- 10 Connect all hoses to their original positions. WARNING: IN EFI MODELS incorrect connection of the fuel hoses to the pump/sender could cause damage to the pump.
- 11 Fit the new steel stabiliser bar mounting blocks (extensions) to the original mounting position on each side of the chassis, and then refit the sway bar to these new mounts.
- 12 Confirm the drain plug has been sealed into the tank and fill with the fuel drained in step 3. Replace the fuel filter under the bonnet after the first 1000km or 2 to 3 tank fills of the new tank and double check mounting bolts. On some diesel vehicles it is necessary to bleed the fuel system after such a tank installation (refer manufacturers handbook).




# Brown Davis Automotive Pty. Ltd.

ABN: 72 657 573 544

Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

## RRIR2

5



PH: +61 (3) 9762 8722 FAX: +61 (3) 9762 9829 47 Holloway Drive, Bayswater, Victoria, Australia 3153



Copyright Brown Davis Automotive Pty. Ltd. This document contains confidential and Technical information the property of Brown Davis Automotive Pty. Ltd.

#### RRIR2

6

## **OPERATION INFORMATION**

The operation of your new Brown Davis Automotive long range fuel tank is little different from the original tank.

Simply fill the long range/auxiliary tank exactly as with a standard tank. (It just takes more fuel to fill, and a dual filler will be used for filling auxiliary tanks).

The fuel gauge on the vehicles dash will read as with the standard tank. It should read with the same degree of accuracy as it did with the standard tank other than staying on full for most of the new increase in capacity. For about 20% more than the standard tank held the gauge will now read in proportion from full down to empty. Auxiliary tanks come with a separate tank gauge to show separate fuel level to main tank.

The low fuel light will still function as normal with it coming "on" at about 20% more fuel volume left to go than it used to, to warn you of low fuel.

Remember your new long range tank(s) are carrying a lot more fuel than standard. Remain aware of how much fuel has been used during the initial period of the gauge remaining on full for future reference in estimating fuel usage and consumption.

Maintenance and service of your new Brown Davis Automotive long range fuel tank other than the recommended 1000km check and filter change should be in align with the normal vehicle Manufactures service schedule and guidelines. Remember the long range tank has a magnetic drain plug that the standard tank did not. With the fuel level low the drain plug can be removed and cleaned to remove any metal fragments introduced from the filler bowser scraping on the filler tube when filling or particles and rust flakes from jerry cans used on long trips. This facility is supplied to protect the in-tank fuel pumps fitted to most modern vehicle fuel tanks.

Finally make sure the warranty card is filled out completely and returned to Brown Davis Automotive and that the warranty information is read and understood. If there are any queries about this or any of the above information please contact us at Brown Davis at the attached address or phone and fax numbers for assistance.