PIRANHA OFFROAD PRODUCTS

BTMBT50T

'Piranha Off Road products are not associated in any way with MAZDA Australia Pty Ltd or any of its related companies'

To Suit MAZDA BT50 2011 - 2015 WITH NO TUB LINER







PARTS INCLUDED WITH TRAY

- 2 X Spacers 8mm
- 2 X M6 30mm
- 2 X M6 50mm
- 2 X M6 15mm
- 2 X M6 Countersunk 25mm
- 6 X M6 Nuts
- 1 X M6 Small Washer
- 2 X M6 Large Washers
- 1 X4 Hole Support Plate
- 1 X 2 Hole Support Plate
- 1 X Top Mount Support Bracket TMBT50 190mm
- 1 X Special Top Mount
- 2 X J Bolts
- 1 X Template

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX

- 1. Place tray in position
- 2. Drill 4 X 6mm holes through plate into wheel arch
- 3. Bolt tray to side of wheel arch with 2X M6 30mm on lower and 2X M6 50mm on upper placing 2 X spacers between plate and body .Check inner guard for bolt protrusion.
- 4. Drill 2 X 6mm holes through base of tray through top of wheel arch.
- 5. Bolt tray to top of wheel arch using support plate under guard with washers with 2 X M6 countersunk 25mm
- 6. Place battery in position secure with J bolts and top mount and top mount support bracket to go between top mount and side rail, secure with 1 X M6 15mm.

ENSURE POSITIVE TERMINAL IS ADEQUATELY COVERED TO PREVENT SHORTING

Nov 2017