# PIRANHA OFFROAD PRODUCTS P/N BTP150P

'Piranha Off Road products are not associated in any way with Toyota Australia or any of its related companies'

# To Suit PRADO 150 SERIES V6 PETROL





### DO NOT LOOSEN TOP NUT













#### PARTS INCLUDED WITH TRAY

- 1 X Tray
- 2 X M8 Countersunk
- 3 X M6 Countersunk
- 2 X M6 Hex
- 3 X M6 Wizlock
- 1 X M6 Body Washer
- 1 X Special Top Mount
- 2 X Special J Bolts
- 1 X M6 Nyloc

## **FITTING INSTRUCTIONS**

#### The cradle fits drivers side front

- 1. Remove power steering reservoir & bracket.
- 2. Remove A/C pipe mount from guard. (Retain rubber mounting block for reinstalling later).
- 3. Manipulate A/C pipe towards engine.
- 4. Re-install rubber A/C pipe mount to top of bracket on pipe.
- 5. Place tray into vehicle & align bolts. Once all bolts are in tray, tighten.
- 6. Re-attach rubber A/C pipe mount to end of trav
- 7. Cut legs off power steering reservoir. Drill two holes through bracket & tray
- 8. Re-mount power steering reservoir. (Note: Dip stick may need to be bent slightly for easier access)
- 9. Place in battery & secure top mount with M6 Nyloc on J-Bolt near air cleaner & through original Toyota mount & tray. Then, drill plastic on radiator support panel & bolt.

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX

Ensure, before closing the bonnet that all items fitted have adequate clearance

Oct 2017