'Piranha Off Road products are not associated in any way with Nissan Motor Co. (Australia) Pty Ltd or any of its related companies'

## To Suit NAVARA / PATHFINDER D40 - 2.5L Diesel

NOT SUITABLE for TI model with dual air conditioning









## PARTS INCLUDED WITH TRAY

- 5 X M8 Bolt Long
- 1 X M8 Bolt Short
- 6 X M8 Nuts
- 2 X M6 Bolts
- 2 X M6 Nuts
- 1 X Special Top Mount

## FITTING INSTRUCTIONS

This tray to the vehicle's chassis, under driver's seat.

Safety First - Place vehicle on hoist, if no hoist available, jack vehicle to a comfortable height and secure with stands.

NOTE: After tray is fitted, terminals are extremely hard to reach. We recommend using an Anderson plug to assist installation. (See image above)

When fitting Optima battery to cradle, ensure the negative terminal is closest to the mounting plate and also make sure the top mount is holding and securing the battery (As seen in first image). Fit cabling before lifting as there is no access once in place. To get the tray into position you will need pry bars to get top mounting plate over the weld bead on top of chassis rail. Move tray as far forward as possible to maximise clearance of exhaust.

Secure tray into position with backing plate using 1 x M8 short bolt first into the top/front hole. Fit all other M8 bolts before tightening.

RECOMMENDED ISOLATOR

DBE140S or DBE180-SX