

Provent Oil Catch Can Kit for Ford Ranger Everest 2022-on 3.0L TD V6 / VW Amarok 2023-on

**KIT No: OS-PROV-49**



## MANN Provent 200 IV Catch Can Kit Install Guide

**STEP 1:** Ensure Engine is OFF and cool enough to work on. Remove Engine Cover

**STEP 2:** Locate the Breather Hose running from the Crank Case (CC) Outlet to the Air Intake (Ai). Using a small flat screwdriver, while placing your other hand over the clip (may spring off!), slide the blade beneath the thin steel clip and lift. Repeat on other end.

*\*\* Re-use the Breather Hose factory fittings for CC (Top Hose) and Ai (Lower Hose).*

*Remove by warming up the hose ends using the following methods: soak in hot water, hair dryer or heat gun.*

**STEP 3:** Identify the Install Area and fit the Provent Bracket below the washer bottle reservoir fill point. **Leftside:** Release and re-use the Air Cleaner support bolt. **Rightside:** Take the supplied 6mm bolt and washer, then screw in to the existing 6mm threaded hole (located near the coolant reservoir). **STEP 4:** Position Provent Ports. **STEP 5:** Details over page.



**STEP 1:**



**STEP 3:**



**STEP 2:**



**STEP 4:**



**STEP 5:**

45-47 Forge St, Blacktown. NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1

# WESTERN FILTERS

MANN Provent Oil Catch Can Kit for Ford Ranger 2022-on 3.0L Turbo Diesel V6 ALL Models

## KIT No: OS-PROV-49

**STEP 5:** Attach Drain Hose (DH) to Provent's base Oil Return drain. Secure with supplied hose clamp. Route DH down inside the wheel arch.

**STEP 6:** Fit Prov200to Bracket.

**STEP 7:** Trim the DH to desired length. Insert the brass 'barbed' fitting of the Tap into the DH and clamp. Secure hose within wheel arch using the supplied P-Clamp. Ensure Tap is in CLOSED position.

**STEP 8: Lower Hose Connection:**

Connect the 'shorter bended-end' to Provent's Lower Outlet.

Insert the factory (Ai) fitting in to the other 'longer bended-end' and secure to the Air Intake.

**STEP 9: Top Hose Connection:** Place the hose in position to check for correct orientation.

Insert the (CC) Fitting and fit to Crank Case. Connect the other end to the Provent Top Inlet. Secure all with clamps.

**STEP 10:** Secure all hoses with cable-ties to avoid any rubbing on wiring. Replace engine cover and your good to go !

**\*\* Maintenance Reminder: Drain the oil catch can monthly ! Replace the element every 40,000 kms.**

To View the Install Slide Presentation: [SCAN QR-CODE](#) on Pg1.



**STEP 6:**



**STEP 7:**



**STEP 8:**



**STEP 9:**



**STEP 10a:**



**STEP 10b:**



**STEP 10c:**

45-47 Forge St, Blacktown, NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1