

LDV T60 MAX 8/2021-on 2.0L Bi-Turbo Diesel 160kW SC20M218

OS-PROV-50



MANN Provent 200 IV Oil Catch Can Kit Install Guide

CAUTION: ** Ensure the engine is OFF & COOL before installation ! **

- STEP 1:** Identify Install Area. Remove Engine and Front Covers.
- STEP 2:** Remove the Breather Hose from between the Crankcase and Air Intake. Re-use Factory Fittings. Push the inner clip in hard !
- STEP 3:** Fit the Provent Bracket using the two factory bolts at the front of the eng.Bay.
- STEP 4:** Release the Provent plastic bracket. Swivel the Ports in to position. Lock in the plastic bracket once more.
- STEP 5:** Feed the Drain Hose down thru the engBay into the wheel arch. Cut to length, insert the Tap (closed position).Secure with clamps.
- STEP 6:** Push the Drain Hose onto the Provent base draining port and clamp tightly.



WESTERN FILTERS

LDV T60 MAX 8/2021-on 2.0L Bi-Turbo Diesel 160kW SC20M218

OS-PROV-50

STEP 7: Fit the Provent to the Kit Bracket, then return the Front Engine Cover.

STEP 8: Air Intake Before: Breather Hose connects to Crankcase.
Air Intake After: Original Fitting connected to Provent Lower Hose.
Air Intake Final: Hose connected to Provent Lower Port Outlet.

STEP 9: Crankcase Before: Breather Hose connects to Air Intake
Crankcase After: Original Fitting connected to Provent Top Hose.
Crankcase Final: Hose connected to Provent Top Inlet Port.

STEP 10: Kit installed / side view: Hoses Cable-tied together to reduce rubbing.
Kit installed / front view: Alternative angle
Return the Eng.Cover and you have successfully installed your Provent Kit !



**** Maintenance Reminder : Drain the oil catch can monthly ! Replace the element every 40,000 kms ****

View Video Slide Presentation: [SCAN QR-CODE on Pg1.](#)



STEP 8:



STEP 9:



STEP 10:

45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1

OS-PROV-50