

Ford Ranger 2022-on 2.0L Bi-Turbo Diesel 157kW 500Nm

OS-PROV-51



MANN Provent 200 IV Oil Catch Can Kit Install Guide

CAUTION: ** Ensure the engine is OFF & COOL before installation ! **

STEP 1: Identify the Install Area.

STEP 2: Fit the Provent Bracket below the washer bottle reservoir fill point.

STEP 3: Route Drain Hose down through the engine bay through to the Wheel Arch.

STEP 4: Position Provent Ports - unclip the back of the Plastic Bracket, swivel the unit, position, reclip bracket.

STEP 5: Attach Drain Hose (DH) to Provent's base Oil Return drain. Secure with supplied hose clamp.

STEP 6: Fit the Provent 200 to the Kit Bracket using the supplied bolts and washers.



STEP 1:



STEP 2:



STEP 3:



STEP 4:



STEP 5:



STEP 6:

45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1

OS-PROV-51

WESTERN FILTERS

Ford Ranger 2022-on 2.0L Bi-Turbo Diesel 157kW 500Nm

OS-PROV-51

- STEP 7:** Trim the Drain Hose to length. Insert the Tap's brass 'Barbed' fitting in to the hose and clamp. Using the supplied P-Clamp, secure Drain Hose with in wheel arch. Ensure Tap is in CLOSED position.
- STEP 8:** Remove the Breather Hose running from the Air Intake to the Crankcase Outlet.
- STEP 9:** Connect the short Lower Hose to Provent's Lower Outlet and the Air Intake.
- STEP 10:** Connect the longer Top Hose to the Provent Top Inlet and the Crankcase Outlet.
- STEP 11:** Clamp all Hose Connections.
Secure all hoses with cable-ties to avoid any rubbing on wiring.

Maintenance Reminder:

Drain the oil catch can monthly ! Replace the element every 40,000 kms.

To View the Youtube Install Slide Presentation: [SCAN QR-CODE on Pg1.](#)



STEP 7:



STEP 8:



STEP 9a:



STEP 9b:



STEP 10a:



STEP 10b:

45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1

OS-PROV-51